

ERRATUM

Notice Maule Gyro trainer références : Z7062001 / Z7062002 / Z7062003 / Z7062004

**Le chargeur USB fourni dans la boîte
est différent du chargeur indiqué dans la notice.
Le nouveau chargeur ne possède pas de led verte**

Voici la nouvelle procédure de charge

Chapitre 5 de la notice :

1. Connectez le chargeur à une prise usb ou à un chargeur de téléphone mobile (non-fourni).
2. Connectez maintenant la batterie au chargeur, la led rouge du chargeur s'allume, signifiant que la charge est en cours.
3. La charge est terminée quand la led rouge s'éteint (durée de la charge 30 minutes environ).

**Rappel : ne jamais effectuer la charge de la batterie sans surveillance !
Se rapporter à la notice originale pour toutes les consignes de sécurité.**

ERRATUM

Maule Gyro trainer Z7062001 / Z7062002 / Z7062003 / Z7062004

**The USB charger supplied in the box
is different from the charger indicated in the manual.
The new charger does not have a green LED.**

Here is the new charging procedure

Chapter 5 of the manual :

1. Connect the charger to a usb socket or cell phone charger (not supplied).
2. Now connect the battery to the charger. The charger's red LED lights up, indicating that charging is in progress.
3. Charging is complete when the red LED goes out (charging time approx. 30 minutes).

**Reminder: never charge the battery unattended!
Refer to the original manual for all safety instructions.**